

TEXT LISTING

068-000519-02

PROGRAM

E130 FLOATING POINT
FIRMWARE EXERCISER

TEXT TAPE

097-000519-02

ABSTRACT

THIS PROGRAM PERFORMS A FUNCTIONAL TEST OF THE
ECLIPSE MODEL 130 FLOATING POINT INSTRUCTION SET.

COPYRIGHT © DATA GENERAL CORPORATION, 1977,78,80
ALL RIGHTS RESERVED. PRINTED IN U.S.A.

ONLY FOR OPERATION AND MAINTENANCE PURPOSES
ON DATA GENERAL CORPORATION MANUFACTURED
EQUIPMENT.

THE AFFIXATION OF A COPYRIGHT NOTICE ON THIS
DIAGNOSTIC MATERIAL IS NOT INTENDED BY ITSELF
TO RENDER THE DISTRIBUTION OF THIS DIAGNOSTIC
MATERIAL A PUBLICATION.

NOTICE

DATA GENERAL CORPORATION (DGC) HAS PREPARED
THIS DIAGNOSTIC MATERIAL FOR USE BY DGC
PERSONNEL AND CUSTOMERS AS A GUIDE TO THE
PROPER MAINTENANCE OF DGC EQUIPMENT AND
SOFTWARE. THE DIAGNOSTIC MATERIALS CONTAINED
HEREIN ARE THE PROPERTY OF DGC AND SHALL
NEITHER BE REPRODUCED IN WHOLE OR IN PART WITHOUT
DGC'S PRIOR WRITTEN APPROVAL NOR BE IMPLIED TO
GRANT ANY LICENSE TO MAKE, USE, OR SELL EQUIPMENT
OR SOFTWARE MANUFACTURED IN ACCORDANCE HEREWITH.

0001 .MAIN

ADS ASSEMBLER REV 03.01 16:26:44 01/10/80

10002 .MAIN

REVISION HISTORY: REFER TO SOURCE CODE

```

01 ;
02 ;
03 ;
04 ;
05 ;
06 ;
07 ;
08 ;
09 ;
10 ;
11 ;
12 ;
13 ;
14 ;
15 ;
16 ;
17 ;
18 ;
19 ;
20 ;
21 ;
22 ;
23 ;
24 ;
25 ;
26 ;
27 ;
28 ;
29 ;
30 ;
31 ;
32 ;
33 ;
34 ;
35 ;
36 ;
37 ;
38 ;
39 ;
40 ;
41 ;
42 ;
43 ;
44 ;
45 ;
46 ;
47 ;
48 ;
49 ;
50 ;
51 ;
52 ;
53 ;
54 ;
55 ;
56 ;
57 ;
58 ;
59 ;
60 ;

```

NAME: E1FPUX.TX PART NUMBER: 097-000519

DESCRIPTION: E130 FLOATING POINT FIRMWARE EXERCISER
TEXT FILE

REVISION HISTORY:

REV.	DATE
00	05/20/77
01	01/27/78
02	01/15/80

COPYRIGHT © DATA GENERAL CORPORATION, 1977, 1978, 1979, 1980
ALL RIGHTS RESERVED.
FOR MAINTENANCE PURPOSES ONLY

THE AFFIXATION OF A COPYRIGHT NOTICE ON THIS
DIAGNOSTIC MATERIAL IS NOT INTENDED BY ITSELF
TO RENDER THE DISTRIBUTION OF THIS DIAGNOSTIC
MATERIAL A PUBLICATION.

NOTICE

DATA GENERAL CORPORATION (DGC) HAS PREPARED
THIS DIAGNOSTIC MATERIAL FOR USE BY DGC PER-
SONNEL AND CUSTOMERS AS A GUIDE TO THE PROPER
MAINTENANCE OF DGC EQUIPMENT AND SOFTWARE.
THE DIAGNOSTIC MATERIALS CONTAINED HEREIN ARE
THE PROPERTY OF DGC AND SHALL NEITHER BE RE-
PRODUCED IN WHOLE OR IN PART WITHOUT DGC'S
PRIOR WRITTEN APPROVAL NOR BE IMPLIED TO GRANT
ANY LICENSE TO MAKE, USE, OR SELL EQUIPMENT OR
SOFTWARE MANUFACTURED IN ACCORDANCE HERewith.
LICENSED MATERIAL - PROPERTY OF DATA GENERAL CORPORATION.

I. MINIMUM MACHINE CONFIGURATION:
ECLIPSE CPU MODEL 130
FLOATING POINT FIRMWARE IN CPU.
8K OR LARGER READ WRITE MEMORY.
TELETYPE OR EQUIVALENT.
LINE PRINTER (OPTIONAL).

II. MAXIMUM MACHINE CONFIGURATION:
ECLIPSE CPU MODEL 130.
FLOATING POINT FIRMWARE IN CPU.
INPUT/OUTPUT TESTER OR DISK.
TELETYPE OR EQUIVALENT.
LINE PRINTER.

III. PROGRAM ABSTRACT:
THIS PROGRAM PERFORMS A FUNCTIONAL TEST OF THE
ECLIPSE MODEL 130 FLOATING POINT INSTRUCTION SET.

IV. RESTRICTIONS:
THIS PROGRAM USES ONLY THE BOTTOM 8K.
OF CORE AND DOES NOT RELOCATE.
THIS PROGRAM DOES NOT USE THE MAP.

V. TEST ALGORITHMS:
THE TEST IS BROKEN UP INTO A SERIES OF SUBTESTS EACH
OF WHICH IS EXECUTED UP TO 100 TIMES IN THE COURSE
OF A SINGLE TEST EXECUTION.

THESE SUBTESTS EXECUTE FLOATING POINT INSTRUCTIONS
WITH RANDOM DATA. THE TESTS ARE DESIGNED TO
GENERATE ONE OF THE ORIGINAL ARGUMENTS AS AN ANSWER.
IF THIS ANSWER IS COMPARED WITH THE ORIGINAL ARGUMENT.
IF THEY ARE NOT EQUAL THE TEST IS SIMULATED IN SOFT-
WARE. THE ORIGINAL ARGUMENT MAY NOT BE RETURNED FOR
A NUMBER OF VALID REASONS, SUCH AS ROUND-OFF ERROR ETC.
ONLY IF THE RESULT DOES NOT AGREE WITH THE
SIMULATOR AS WELL, IS AN ERROR GENERATED.

IN THE EVENT OF AN ERROR THE RESULTS AND
EXPECTED RESULTS ARE OUTPUT TO THE CONSOLE
I/O DEVICE AND/OR THE LINE PRINTER.

IN THE CASE OF SUBTESTS CHECKING SKIP OPERATIONS THE
SKIP IS CHECKED TO MAKE SURE IT DOES NOT SKIP WHEN
IT ISN'T SUPPOSED TO. THE CONDITION REQUIRED FOR
THE SKIP IS THEN GENERATED AND THE INSTRUCTION
TRIED FOR THE PROPER RESPONSE.
A SPECIAL MESSAGE IS PRINTED IN THE EVENT OF A
SKIP ERROR.

LASTLY SKIPS ARE SOMETIMES USED TO CHECK THE RESULTS
OF A COMPUTATION. THIS VERIFIES THAT THE CALCULATION
SET THE PROPER STATUS BITS AS WELL AS THE SKIPS
OPERATION.

0003 .MAIN

VI.

PROGRAM MODES:

THE DIFFERENT MODES OF OPERATION OF THIS PROGRAM ARE SELECTED FROM THE SWITCH REGISTER AS FOLLOWS:

SW0 = 1 USE THE CONSOLE SWITCHES.
 = 0 USE THE SWITCHES PASSED FROM DTOS OR AS STORED AT START.

SW1 = 1 CONTINUE AFTER ERROR.
 SW2 = 1 INHIBIT OUTPUT TO TELETYPE.
 SW3 = 1 PRINT FAILURE RATE.
 SW4 = 1 INHIBIT PASS COUNT OUTPUT.
 SW5 = 1 ENABLE OUTPUT TO LINE PRINTER.

IF SWITCH ZERO (SW0) IS SET TO ZERO AND THE PROGRAM IS LOADED FROM DTOS WITH A SELECT OR RUN COMMAND THE PROGRAM WILL USE THE SWITCHES PASSED FROM DTOS. (SEE SWREG COMMAND IN THE DTOS MANUAL.)

IF SW0 IS ONE DATA SWITCHES 6-15 MUST (1) BE ZERO.

VII. OPERATING PROCEDURES:

A. LOADING STAND ALONE.
 LOAD THE PROGRAM USING THE BINARY LOADER. THE PROGRAM SHOULD BE LOADED AT LOCATION ZERO.

IF THE DATA CHANNEL TESTER (CAT/KITTEM) PROGRAMS HAVE BEEN LOADED ALSO, START AT LOCATION 171.

IF THE CAT/KITTEM PROGRAMS HAVE NOT BEEN LOADED, START AT LOCATION 170.

ONCE STARTED, THE PROGRAM WILL EXECUTE ALL TESTS INDEFINITELY, LOOPING UNTIL MANUALLY INTERRUPTED.

B. LOADING FROM DTOS.
 THIS DIAGNOSTIC MAY BE LOADED IN EITHER AUTO-MODE OR MANUAL-MODE, USING THE NORMAL DTOS COMMANDS.

C. NORMAL OPERATION.
 WHEN THE PROGRAM IS RUN STAND-ALONE, OR IS LOADED WITH A DTOS MANUAL MODE COMMAND, THE PROGRAM WILL REQUEST THE OPERATOR TO SET THE SWITCHES. RESUME THE PROGRAM BY PRESSING 'CONTINUE' ON THE CPU CONSOLE. DEFAULT SWITCHES ARE ALL ZERO.

WHEN THE PROGRAM IS CONTINUED THE SWITCHES ARE STORED. SWITCH ZERO MAY NOW BE SET TO ZERO SO OTHER CPU CONSOLE FEATURES (SUCH AS MONITORING A LOCATION), MAY BE USED.

10004 .MAIN

D. NORMAL PROGRAM TERMINATION.

IN AUTO MODE THE PROGRAM WILL RUN FOR SEVEN PASSES. AT THE END OF EACH PASS THE WORD "PASS" AND THE FLOATING POINT ACCUMULATORS JUST TESTED WILL BE PRINTED. AFTER THE SEVENTH PASS THE PROGRAM RETURNS TO DTOS.

IN MANUAL MODE THE PROGRAM PRINTS THE SAME MESSAGE AS ABOVE AFTER EACH PASS, HOWEVER THE PROGRAM WILL NOT AUTOMATICALLY RETURN TO DTOS.

E. ERRORS.

WHEN THE PROGRAM IS IN AUTO MODE THE PROGRAM PRINTS AN ERROR MESSAGE AND RETURNS TO DTOS IMMEDIATELY ON AN ERROR.

WHEN IN MANUAL MODE, AND USING THE DEFAULT SWITCHES, THE PROGRAM PRINTS OUT AN ERROR MESSAGE AND THEN LOOPS ON THE FAILING SUB-TEST. IF THE PROBLEM IS INTERMITTENT SW3 MAY BE SET. THE PROGRAM THEN PRINTS OUT THE RATIO OF TIMES THE SUBTEST FAILED TO THE NUMBER OF TIMES THE SUBTEST HAS BEEN EXECUTED AS A PERCENTAGE. IF SW1 IS SET THE PROGRAM CONTINUES WITH THE REST OF THE TEST.

01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27

```

10005 .MAIN
01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50

```

```

? VIII. PROGRAM DIAGNOSTIC OUTPUTS:
? IN THE EVENT OF AN ERROR THE PROGRAM MAY OUTPUT
? ONE OF SEVERAL MESSAGES. THESE ARE LISTED
? BELOW. A STRING OF "0"'S INDICATES A NUMBER
? PRINTED IN OCTAL FORMAT. A STRING OF "H"'S INDICATES
? A NUMBER IN HEXADECIMAL FORMAT.
?
? A. FLOATING POINT STATUS REGISTER TEST ERROR.
?
? ERROR IN TEST AT LOC. 000000
?
? EXPECTED STATUS 000000
? STATUS READ
?
? THE STATUS INFORMATION IS SELF EXPLANATORY
? THE LOCATION GIVEN IS THE ADDRESS OF
? THE START OF THE SUBTEST, NOT THE
? ACTUAL LOCATION OF THE ERROR.
?
? B. FLOATING POINT SKIP TEST ERROR.
?
? SKIP ERROR AT THE FOLLOWING LOCATION:
? PC=
? 000000
?
? IN THE EVENT A SKIP INSTRUCTION DOES NOT
? PERFORM AS EXPECTED THIS MESSAGE IS
? OUTPUT. THE PC LOCATION MENTIONED IS THAT
? OF THE ERROR CALL. THE FAILING INSTRUCTION
? IS THE FIRST SKIP INSTRUCTION PRIOR TO
? THE ERROR CALL.
?
? C. ARITHMETIC OPERATION TEST ERROR.
?
? ERROR IN TEST AT LOC. 000000
?
? CORRECT BUFF <A,B,C> HHHH HHHH [HHHH HHHH]
? BUFF <A,B,C> HHHH HHHH [HHHH HHHH]
?
? THIS FORMAT IS USED WHEN TESTING INSTRUCTIONS
? THAT STORE THEIR RESULTS INTO MEMORY.
?
? THE LOCATION GIVEN IS THE ADDRESS OF THE START
? OF THE SUBTEST FAILING. THIS IS FOLLOWED BY
? THE NAME OF THE BUFFER CONTAINING THE EXPECTED
? ANSWER AND THE VALUE EXPECTED (EXPRESSED IN
? HEX. THE LAST 8 DIGITS ARE DISPLAYED
? ONLY FOR DOUBLE PRECISION).
? THE NAME OF THE BUFFER CONTAINING
? THE RESULTS OF THE OPERATION
? FOLLOWS USING THE SAME FORMAT.

```

```

10006 .MAIN
01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52

```

```

? ANOTHER VARIATION OF THIS ERROR FORMAT
? IS SHOWN BELOW:
?
? ERROR IN TEST AT LOC. 000000
?
? CORRECT BUFF <A,B,C> HHHH HHHH [HHHH HHHH]
? (FPAC) HHHH HHHH [HHHH HHHH]
?
? THE LOCATION SPECIFIED IN THIS MESSAGE IS THE
? SAME AS IN THE LAST FORMAT. THE TERM FPAC
? REFERS TO THE FLOATING POINT ACCUMULATOR UNDER
? TEST THIS PASS, AND CHANGES FROM PASS TO
? PASS.
?
? LASTLY THERE IS A SPECIAL FORMAT TO DEAL WITH
? THOSE INSTRUCTIONS WHICH MODIFY THE CPU'S
? ACCUMULATORS AS SHOWN BELOW:
?
? ERROR IN TEST AT LOC. 000000
?
? (AC0) 00000 HHHH
? (AC1) 00000 HHHH
? (AC2) 00000 HHHH
?
? THE ERROR LOCATION INFORMATION IS THE SAME
? AS BEFORE. THE SIGNIFICANCE OF THE
? ACCUMULATORS PRINTED OUT MUST BE DETERMINED
? BY EXAMINING THE SUBTEST.
?
? D. FLOATING INTEGERIZE TEST ERROR.
?
? 000000 0 000000 000000 000000
? 000000 000000
?
? HHHH HHHH HHHH HHHH
? HHHH HHHH HHHH HHHH
? HHHH HHHH HHHH HHHH
?
? THIS IS ESSENTIALLY A STATE DUMP OF THE CPU.
? THE FIRST LINE IN ORDER CONTAINS:
? THE PC OF THE ERROR CALL, THE STATE OF THE
? CARRY, AND THE CONTENTS OF THE CPU'S ACS.
?
? THE TWO ENTRIES ON THE NEXT LINE DISPLAY THE
? STATE OF THE FLOATING POINT STATUS REGISTER.
?
? THE NEXT FOUR LINES ARE THE CONTENTS OF
? FLOATING POINT ACCUMULATORS 0 -> 3.

```

10007 .MAIN

? IX. HELPFUL HINTS:

? THE PROGRAM HAS A DATA BLOCK BEGINNING AT
? LOCATION 200 TO AID IN MONITORING THE PROGRAM
? FOR CORRECT FUNCTION. THE MOST USEFUL OF
? THE ENTRIES IN THIS BLOCK IS AT LOCATION 201.
? THIS ENTRY ALWAYS CONTAINS THE ADDRESS OF
? THE SUBTEST CURRENTLY BEING EXECUTED.

? ADDITIONAL INFORMATION MAY BE FOUND IN:

? PROGRAMERS REFERENCE MANUAL FOR THE ECLIPSE S-130.
? &
? DIAGNOSTIC TAPE OPERATING SYSTEM REFERENCE MANUAL.

?#####
? IN ORDER TO COMPLETELY TEST THE FLOATING POINT
? FIRMWARE IN THE ECLIPSE 130, BOTH THE FLOATING
? POINT DIAGNOSTIC, AND THE FLOATING POINT
? EXERCISER MUST BE RUN WITH CAT/KITTEN I
?#####

10008 .MAIN
01 000000 .TXTM 0

**000000 TOTAL ERRORS, 000000 FIRST PASS ERRORS